

GEYA



SWITCH
SOCKET
POWER THE WAY OF LIFE

 **ELECTRICAL**
PRODUCTS ACCESSORIES









D2
Series

SWITCH





SOCKET

Picture	Model No.	Picture	Model No.
	D2-001 Door Bell Switch		D2-015 Double 4 Pin Socket
	D2-002 1Gang 1 Way Switch		D2-016 1 gang 1 way+4 pin socket
	D2-003 1Gang 2 Way Switch		D2-017 1 gang 2 way+4 pin socket
	D2-004 1Gang 1 Way Switch		D2-018 1 Gang 1 Way+2 Pin Socket
	D2-005 1Gang 2 Way Switch		D2-019 1 Gang 2 Way+2 Pin Socket
	D2-006 2Gang 1 Way Switch		D2-020 3 Pole Socket
	D2-007 2Gang 2 Way Switch		D2-021 Double 3 Pole Socket
	D2-008 3Gang 1 Way Switch		D2-022 Triple 3 Pole Socket
	D2-009 3Gang 2 Way Switch		D2-023 1 Gang 1 Way Switch+3 Pole Socket
	D2-010 6Gang 1 Way Switch		D2-024 1 Gang 2 Way Switch+3 Pole Socket
	D2-011 6Gang 2 Way Switch		D2-025 1 Gang 1 Way Switch+double 3 Pole Socket
	D2-012 2 Pin socket		D2-026 1 Gang 2 Way Switch+double 3 Pole Socket
	D2-013 Double 2 Pin socket		D2-027 2 Gang 1 Way Switch+3 Pole Socket
	D2-014 Triple 2 Pin Socket		D2-028 2 Gang 2 Way Switch+3 Pole Socket

Picture	Model No.	Picture	Model No.
	D2-029 Thailand 3 Pole socket		D2-039 1/2 Double USB Socket 2.1A
	D2-030 Double Thailand 3 Pole socket		D2-040 Double thailand 3 pole socket with 2 USB socket 2.1A
	D2-031 Triple Thailand 3 Pole socket		D2-041 Double 3 pole socket with 2 USB socket 2.1A
	D2-032 1 Gang 1 Way Switch+Thailand Socket		D2-042 Satellite Socket
	D2-033 1 Gang 2 Way Switch+Thailand Socket		D2-043 Tel Socket
	D2-034 2/3MF Socket		D2-044 Computer Socket
	D2-035 2/3MF Socket+2 Pin Socket		D2-045 Satellite Tel socket
	D2-036 1/2MF Socket		D2-046 Satellite Computer Socket
	D2-037 Double MF Socket		D2-047 Voice control switch
	D2-038 1/3 Double USB Socket 2.1A		D2-048 Touch Delay Switch
			D2-049 Dimmer Switch
			D2-050 Speed Control Switch


118 - D2


Elegant White
Switch and socket



Picture	Model No.	Picture	Model No.
	D2-051 American 20A socket		D2-061 45A switch with neon
	D2-052 American 20A socket+ 1 gang 1 way		D2-062 45A switch with neon+ 2 Pin Socket
	D2-053 American 20A socket+ 1 gang 2 way		
	D2-054 16A Germany Socket		D2-063 1/3 10A Italian Socket
	D2-055 16A Germany Socket+2USB		D2-064 Triple 1/3 10A Italian Socket
	D2-056 Insert Card for Power		D2-065 1 gang 1 way+Double 10A Italian Socket
			D2-066 1 gang 2 way+Double 10A Italian Socket
	D2-057 Footlight		D2-067 1/3 16A Italian Socke
	D2-058 Body Sensor Switch		D2-068 Triple 1/3 16A Italian Socket
	D2-059 Body Sensor Switch with Footlight		D2-069 1 gang 1 way+Double 16A Italian Socket
			D2-070 1 gang 2 way+Double 16A Italian Socket
	D2-060 20A indi cator+2 Pin Socket		D2-071 British 13A socket

118 - D2

Elegant White
Switch and socket

Picture	Model No.	Picture	Model No.
	D2-072 British 13A socket+ 1 gang 1 way		D2-080 Universal GFCI Socket
	D2-073 British 13A socket+ 1 gang 2 way		
	D2-074 Emergency lamp		D2-081 American 20A & GFCI socket
	D2-075 Buzzer		D2-082 The curtain switch
	D2-076 Blank plate		D2-083 HDMI Socket+VGA Socket
	D2-077 Dimmer Switch+Satelite Socket		D2-084 Audio Socket+Double Audio Socket
	D2-078 Speed Control Switch+TEL Socket		D2-085 Circuit breaker bracket
	D2-079 American GFCI Socket		D2-086 3 Pole Socket with TYPE-A+TYPE-C socket


Picture	Model No.	Picture	Model No.
	D2-001 Door Bell Switch		D2-015 Double 4 Pin Socket
	D2-002 1Gang 1 Way Switch		D2-016 1 gang 1 way+4 pin socket
	D2-003 1Gang 2 Way Switch		D2-017 1 gang 2 way+4 pin socket
	D2-004 1Gang 1 Way Switch		D2-018 1 Gang 1 Way+2 Pin Socket
	D2-005 1Gang 2 Way Switch		D2-019 1 Gang 2 Way+2 Pin Socket
	D2-006 2Gang 1 Way Switch		D2-020 3 Pole Socket
	D2-007 2Gang 2 Way Switch		D2-021 Double 3 Pole Socket
	D2-008 3Gang 1 Way Switch		D2-022 Triple 3 Pole Socket
	D2-009 3Gang 2 Way Switch		D2-023 1 Gang 1 Way Switch+3 Pole Socket
	D2-010 6Gang 1 Way Switch		D2-024 1 Gang 2 Way Switch+3 Pole Socket
	D2-011 6Gang 2 Way Switch		D2-025 1 Gang 1 Way Switch+double 3 Pole Socket
	D2-012 2 Pin socket		D2-026 1 Gang 2 Way Switch+double 3 Pole Socket
	D2-013 Double 2 Pin socket		D2-027 2 Gang 1 Way Switch+3 Pole Socket
	D2-014 Triple 2 Pin Socket		D2-028 2 Gang 2 Way Switch+3 Pole Socket








Picture	Model No.	Picture	Model No.
	D2-029 Thailand 3 Pole socket		D2-039 1/2 Double USB Socket 2.1A
	D2-030 Double Thailand 3 Pole socket		D2-040 Double thailand 3 pole socket with 2 USB socket 2.1A
	D2-031 Triple Thailand 3 Pole socket		D2-041 Double 3 pole socket with 2 USB socket 2.1A
	D2-032 1 Gang 1 Way Switch+Thailand Socket		D2-042 Satellite Socket
	D2-033 1 Gang 2 Way Switch+Thailand Socket		D2-043 Tel Socket
	D2-034 2/3MF Socket		D2-044 Computer Socket
	D2-035 2/3MF Socket+2 Pin Socket		D2-045 Satellite Tel socket
	D2-036 1/2MF Socket		D2-046 Satellite Computer Socket
	D2-037 Double MF Socket		D2-047 Voice control switch
	D2-038 1/3 Double USB Socket 2.1A		D2-048 Touch Delay Switch
			D2-049 Dimmer Switch
			D2-050 Speed Control Switch



















118 - D2 Elegant White Switch and socket

Picture	Model No.	Picture	Model No.
	D2-051 American 20A socket		D2-061 45A switch with neon
	D2-052 American 20A socket+ 1 gang 1 way		D2-062 45A switch with neon+ 2 Pin Socket
	D2-053 American 20A socket+ 1 gang 2 way		
	D2-054 16A Germany Socket		D2-063 1/3 10A Italian Socket
	D2-055 16A Germany Socket+2USB		D2-064 Triple 1/3 10A Italian Socket
	D2-056 Insert Card for Power		D2-065 1 gang 1 way+Double 10A Italian Socket
			D2-066 1 gang 2 way+Double 10A Italian Socket
	D2-057 Footlight		D2-067 1/3 16A Italian Socket
	D2-058 Body Sensor Switch		D2-068 Triple 1/3 16A Italian Socket
	D2-059 Body Sensor Switch with Footlight		D2-069 1 gang 1 way+Double 16A Italian Socket
			D2-070 1 gang 2 way+Double 16A Italian Socket
	D2-060 20A indicator+2 Pin Socket		D2-071 British 13A socket

118 - D2 Elegant White Switch and socket










Picture	Model No.	Picture	Model No.
	D2-072 British 13A socket+ 1 gang 1 way		D2-080 Universal GFCI Socket
	D2-073 British 13A socket+ 1 gang 2 way		
	D2-074 Emergency lamp		D2-081 American 20A & GFCI socket
	D2-075 Buzzer		D2-082 The curtain switch
	D2-076 Blank plate		D2-083 HDMI Socket+VGA Socket
	D2-077 Dimmer Switch+Satelite Socket		D2-084 Audio Socket+Double Audio Socket
	D2-078 Speed Control Switch+TEL Socket		D2-085 Circuit breaker bracket
	D2-079 American GFCI Socket		D2-086 3 Pole Socket with TYPE-A+TYPE-C socket

Picture	Model No.	Picture	Model No.
	D2-001 Door Bell Switch		D2-015 Double 4 Pin Socket
	D2-002 1Gang 1 Way Switch		D2-016 1 gang 1 way+4 pin socket
	D2-003 1Gang 2 Way Switch		D2-017 1 gang 2 way+4 pin socket
	D2-004 1Gang 1 Way Switch		D2-018 1 Gang 1 Way+2 Pin Socket
	D2-005 1Gang 2 Way Switch		D2-019 1 Gang 2 Way+2 Pin Socket
	D2-006 2Gang 1 Way Switch		D2-020 3 Pole Socket
	D2-007 2Gang 2 Way Switch		D2-021 Double 3 Pole Socket
	D2-008 3Gang 1 Way Switch		D2-022 Triple 3 Pole Socket
	D2-009 3Gang 2 Way Switch		D2-023 1 Gang 1 Way Switch+3 Pole Socket
	D2-010 6Gang 1 Way Switch		D2-024 1 Gang 2 Way Switch+3 Pole Socket
	D2-011 6Gang 2 Way Switch		D2-025 1 Gang 1 Way Switch+double 3 Pole Socket
	D2-012 2 Pin socket		D2-026 1 Gang 2 Way Switch+double 3 Pole Socket
	D2-013 Double 2 Pin socket		D2-027 2 Gang 1 Way Switch+3 Pole Socket
	D2-014 Triple 2 Pin Socket		D2-028 2 Gang 2 Way Switch+3 Pole Socket

Picture	Model No.	Picture	Model No.
	D2-029 Thailand 3 Pole socket		D2-039 1/2 Double USB Socket 2.1A
	D2-030 Double Thailand 3 Pole socket		D2-040 Double thailand 3 pole socket with 2 USB socket 2.1A
	D2-031 Triple Thailand 3 Pole socket		D2-041 Double 3 pole socket with 2 USB socket 2.1A
	D2-032 1 Gang 1 Way Switch+Thailand Socket		D2-042 Satellite Socket
	D2-033 1 Gang 2 Way Switch+Thailand Socket		D2-043 Tel Socket
	D2-034 2/3MF Socket		D2-044 Computer Socket
	D2-035 2/3MF Socket+2 Pin Socket		D2-045 Satellite Tel socket
	D2-036 1/2MF Socket		D2-046 Satellite Computer Socket
	D2-037 Double MF Socket		D2-047 Voice control switch
	D2-038 1/3 Double USB Socket 2.1A		D2-048 Touch Delay Switch
			D2-049 Dimmer Switch
			D2-050 Speed Control Switch








118 - D2

Elegant White
Switch and socket









Picture	Model No.	Picture	Model No.
	D2-051 American 20A socket		D2-061 45A switch with neon
	D2-052 American 20A socket+ 1 gang 1 way		D2-062 45A switch with neon+ 2 Pin Socket
	D2-053 American 20A socket+ 1 gang 2 way		
	D2-054 16A Germany Socket		D2-063 1/3 10A Italian Socket
	D2-055 16A Germany Socket+2USB		D2-064 Triple 1/3 10A Italian Socket
	D2-056 Insert Card for Power		D2-065 1 gang 1 way+Double 10A Italian Socket
			D2-066 1 gang 2 way+Double 10A Italian Socket
	D2-057 Footlight		D2-067 1/3 16A Italian Socket
	D2-058 Body Sensor Switch		D2-068 Triple 1/3 16A Italian Socket
	D2-059 Body Sensor Switch with Footlight		D2-069 1 gang 1 way+Double 16A Italian Socket
			D2-070 1 gang 2 way+Double 16A Italian Socket
	D2-060 20A indicator+2 Pin Socket		D2-071 British 13A socket

118 - D2




Elegant White
Switch and socket

Picture	Model No.	Picture	Model No.
	D2-072 British 13A socket+ 1 gang 1 way		D2-080 Universal GFCI Socket
	D2-073 British 13A socket+ 1 gang 2 way		
	D2-074 Emergency lamp		D2-081 American 20A & GFCI socket
	D2-075 Buzzer		D2-082 The curtain switch
	D2-076 Blank plate		D2-083 HDMI Socket+VGA Socket
	D2-077 Dimmer Switch+Satelite Socket		D2-084 Audio Socket+Double Audio Socket
	D2-078 Speed Control Switch+TEL Socket		D2-085 Circuit breaker bracket
	D2-079 American GFCI Socket		D2-086 3 Pole Socket with TYPE-A+TYPE-C socket

118 – D2 Elegant White Switch and socket





Picture	Model No.	Picture	Model No.
	D2-001 Door Bell Switch		D2-015 Double 4 Pin Socket
	D2-002 1Gang 1 Way Switch		D2-016 1 gang 1 way+4 pin socket
	D2-003 1Gang 2 Way Switch		D2-017 1 gang 2 way+4 pin socket
	D2-004 1Gang 1 Way Switch		D2-018 1 Gang 1 Way+2 Pin Socket
	D2-005 1Gang 2 Way Switch		D2-019 1 Gang 2 Way+2 Pin Socket
	D2-006 2Gang 1 Way Switch		D2-020 3 Pole Socket
	D2-007 2Gang 2 Way Switch		D2-021 Double 3 Pole Socket
	D2-008 3Gang 1 Way Switch		D2-022 Triple 3 Pole Socket
	D2-009 3Gang 2 Way Switch		D2-023 1 Gang 1 Way Switch+3 Pole Socket
	D2-010 6Gang 1 Way Switch		D2-024 1 Gang 2 Way Switch+3 Pole Socket
	D2-011 6Gang 2 Way Switch		D2-025 1 Gang 1 Way Switch+double 3 Pole Socket
	D2-012 2 Pin socket		D2-026 1 Gang 2 Way Switch+double 3 Pole Socket
	D2-013 Double 2 Pin socket		D2-027 2 Gang 1 Way Switch+3 Pole Socket
	D2-014 Triple 2 Pin Socket		D2-028 2 Gang 2 Way Switch+3 Pole Socket

118 – D2 Elegant White Switch and socket

Picture	Model No.	Picture	Model No.
	D2-029 Thailand 3 Pole socket		D2-039 1/2 Double USB Socket 2.1A
	D2-030 Double Thailand 3 Pole socket		D2-040 Double thailand 3 pole socket with 2 USB socket 2.1A
	D2-031 Triple Thailand 3 Pole socket		D2-041 Double 3 pole socket with 2 USB socket 2.1A
	D2-032 1 Gang 1 Way Switch+Thailand Socket		D2-042 Satellite Socket
	D2-033 1 Gang 2 Way Switch+Thailand Socket		D2-043 Tel Socket
	D2-034 2/3MF Socket		D2-044 Computer Socket
	D2-035 2/3MF Socket+2 Pin Socket		D2-045 Satellite Tel socket
	D2-036 1/2MF Socket		D2-046 Satellite Computer Socket
	D2-037 Double MF Socket		D2-047 Voice control switch
	D2-038 1/3 Double USB Socket 2.1A		D2-048 Touch Delay Switch
			D2-049 Dimmer Switch
			D2-050 Speed Control Switch



118 - D2

Elegant White
Switch and socket

Picture	Model No.	Picture	Model No.
	D2-051 American 20A socket		D2-061 45A switch with neon
	D2-052 American 20A socket+ 1 gang 1 way		D2-062 45A switch with neon+ 2 Pin Socket
	D2-053 American 20A socket+ 1 gang 2 way		
	D2-054 16A Germany Socket		D2-063 1/3 10A Italian Socket
	D2-055 16A Germany Socket+2USB		D2-064 Triple 1/3 10A Italian Socket
	D2-056 Insert Card for Power		D2-065 1 gang 1 way+Doubole 10A Italian Socket
			D2-066 1 gang 2 way+Doubole 10A Italian Socket
	D2-057 Footlight		D2-067 1/3 16A Italian Socke
	D2-058 Body Sensor Swith		D2-068 Triple 1/3 16A Italian Socket
	D2-059 Body Sensor Swith with Footlight		D2-069 1 gang 1 way+Doubole 16A Italian Socket
			D2-070 1 gang 2 way+Doubole 16A Italian Socket
	D2-060 20A indi cator+2 Pin Socket		D2-071 British 13A socket

118 - D2

Elegant White
Switch and socket

Picture	Model No.	Picture	Model No.
	D2-072 British 13A socket+ 1 gang 1 way		D2-080 Universal GFCI Socket
	D2-073 British 13A socket+ 1 gang 2 way		
	D2-074 Emergency lamp		D2-081 American 20A & GFCI socket
	D2-075 Buzzer		D2-082 The curtain switch
	D2-076 Blank plate		D2-083 HDMI Socket+VGA Socket
	D2-077 Dimmer Switch+Satelite Socket		D2-084 Audio Socket+Double Audio Socket
	D2-078 Speed Control Switch+TEL Socket		D2-085 Circuit breaker bracket
	D2-079 American GFCI Socket		D2-086 3 Pole Socket with TYPE-A+TYPE-C socket