




GEYA



The true colors of
elegance



WHITE



ORANGE



GREY



BLACK





LY1-001
1 gang 1 way plate switch
LY1-002
1 gang 2 way plate switch
LY1-003
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-004
2 gang 1 way plate switch
LY1-005
2 gang 2 way plate switch
LY1-006
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-007
3 gang 1 way plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-008
1 gang 1 way plate switch with LED light
LY1-009
1 gang 2 way plate switch with LED light
LY1-010
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-011
2 gang 1 way plate switch with LED light
LY1-012
2 gang 2 way plate switch with LED light
LY1-013
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-014
One German socket not
groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-015
One German socket with
groundground
13A/250V~
10pcs/box 100pcs/ctn



LY1-016
French socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-017
One German socket with
groundground and Double USB
16A/250V~
8pcs/box 80pcs/ctn



LY1-018
One German socket with
groundground and A+TYPE C
16A/250V~
8pcs/box 80pcs/ctn



LY1-019
One German socket not
groundground with Double USB
(A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-020
One German socket not
groundground with Double USB
(A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-021
French socket with Double
USB(A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-022
French socket with Double
USB(A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-023
Double USB
(A+TYPE C, PD 20W)
16A/250V~
10pcs/box 100pcs/ctn



LY1-024
TV socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-025
Satellite socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-026
TEL socket
LY1-027
Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-028
Double TEL Socket
LY1-029
TEL+Computer(cat6A) socket
LY1-030
Double Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-031
TV+TEL Socket
LY1-032
TV+Computer Socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-033
Light dimmer switch(500W)
LY1-034
Adjust speed
16A/250V~
10pcs/box 100pcs/ctn




LY1-035
One waterproof German
socket not groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
socket with ground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
French socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-036
Double German socket
with groundground
16A/250V~
5pcs/box 50pcs/ctn



LY1-037
Double German socket
not groundground
16A/250V~
5pcs/box 50pcs/ctn



LY1-038
Double French socket
16A/250V~
5pcs/box 50pcs/ctn



LY1-039
3pin socket



LY1-040
4pin socket



LY1-001
1 gang 1 way plate switch
LY1-002
1 gang 2 way plate switch
LY1-003
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-004
2 gang 1 way plate switch
LY1-005
2 gang 2 way plate switch
LY1-006
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-007
3 gang 1 way plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-008
1 gang 1 way plate switch with LED light
LY1-009
1 gang 2 way plate switch with LED light
LY1-010
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-011
2 gang 1 way plate switch with LED light
LY1-012
2 gang 2 way plate switch with LED light
LY1-013
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-014
One German socket not
groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-015
One German socket with
groundground
13A/250V~
10pcs/box 100pcs/ctn



LY1-016
French socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-017
One German socket with
groundground and Double USB
16A/250V~
8pcs/box 80pcs/ctn



LY1-018
One German socket with
groundground and A+TYPE C
16A/250V~
8pcs/box 80pcs/ctn



LY1-019
One German socket not
groundground with Double USB
(A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-020
One German socket not
groundground with Double USB
(A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-021
French socket with Double
USB(A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-022
French socket with Double
USB(A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-023
Double USB
(A+TYPE C, PD 20W)
16A/250V~
10pcs/box 100pcs/ctn



LY1-024
TV socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-025
Satellite socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-026
TEL socket
LY1-027
Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-028
Double TEL Socket
LY1-029
TEL+Computer(cat6A) socket
LY1-030
Double Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-031
TV+TEL Socket
LY1-032
TV+Computer Socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-033
Light dimmer switch(500W)
LY1-034
Adjust speed
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
socket not groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
socket with ground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
French socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-036
Double German socket
with groundground
16A/250V~
5pcs/box 50pcs/ctn



LY1-037
Double German socket
not groundground
16A/250V~
5pcs/box 50pcs/ctn



LY1-038
Double French socket
16A/250V~
5pcs/box 50pcs/ctn



LY1-039
3pin socket



LY1-040
4pin socket



LY1-001
1 gang 1 way plate switch
LY1-002
1 gang 2 way plate switch
LY1-003
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-004
2 gang 1 way plate switch
LY1-005
2 gang 2 way plate switch
LY1-006
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-007
3 gang 1 way plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-008
1 gang 1 way plate switch with LED light
LY1-009
1 gang 2 way plate switch with LED light
LY1-010
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-011
2 gang 1 way plate switch with LED light
LY1-012
2 gang 2 way plate switch with LED light
LY1-013
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-014
One German socket not groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-015
One German socket with groundground
13A/250V~
10pcs/box 100pcs/ctn



LY1-016
French socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-017
One German socket with groundground and Double USB
16A/250V~
8pcs/box 80pcs/ctn



LY1-018
One German socket with groundground and A+TYPE C
16A/250V~
8pcs/box 80pcs/ctn



LY1-019
One German socket not groundground with Double USB (A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-020
One German socket not groundground with Double USB (A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-021
French socket with Double USB (A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-022
French socket with Double USB (A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-023
Double USB (A+TYPE C, PD 20W)
16A/250V~
10pcs/box 100pcs/ctn



LY1-024
TV socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-025
Satellite socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-026
TEL socket
LY1-027
Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-028
Double TEL Socket
LY1-029
TEL+Computer(cat6A) socket
LY1-030
Double Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-031
TV+TEL Socket
LY1-032
TV+Computer Socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-033
Light dimmer switch(500W)
LY1-034
Adjust speed
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German socket not groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German socket with ground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German French socket
16A/250V~
10pcs/box 100pcs/ctn




LY1-036
Double German socket with groundground
16A/250V~
5pcs/box 50pcs/ctn




LY1-037
Double German socket not groundground
16A/250V~
5pcs/box 50pcs/ctn



LY1-038
Double French socket
16A/250V~
5pcs/box 50pcs/ctn



LY1-039
3pin socket



LY1-040
4pin socket



LY1-001
1 gang 1 way plate switch
LY1-002
1 gang 2 way plate switch
LY1-003
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-004
2 gang 1 way plate switch
LY1-005
2 gang 2 way plate switch
LY1-006
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-007
3 gang 1 way plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-008
1 gang 1 way plate switch with LED light
LY1-009
1 gang 2 way plate switch with LED light
LY1-010
1 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-011
2 gang 1 way plate switch with LED light
LY1-012
2 gang 2 way plate switch with LED light
LY1-013
2 gang resetting plate switch
16A/250V~
10pcs/box 100pcs/ctn



LY1-014
One German socket not
groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-015
One German socket with
groundground
13A/250V~
10pcs/box 100pcs/ctn



LY1-016
French socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-017
One German socket with
groundground and Double USB
16A/250V~
8pcs/box 80pcs/ctn



LY1-018
One German socket with
groundground and A+TYPE C
16A/250V~
8pcs/box 80pcs/ctn



LY1-019
One German socket not
groundground with Double USB
(A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-020
One German socket not
groundground with Double USB
(A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-021
French socket with Double
USB(A+A, 5V 2.1A)
16A/250V~
8pcs/box 80pcs/ctn



LY1-022
French socket with Double
USB(A+TYPE C, PD 20W)
16A/250V~
8pcs/box 80pcs/ctn



LY1-023
Double USB
(A+TYPE C, PD 20W)
16A/250V~
10pcs/box 100pcs/ctn



LY1-024
TV socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-025
Satellite socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-026
TEL socket
LY1-027
Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-028
Double TEL Socket
LY1-029
TEL+Computer(cat6A) socket
LY1-030
Double Computer(cat6A) socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-031
TV+TEL Socket
LY1-032
TV+Computer Socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-033
Light dimmer switch(500W)
LY1-034
Adjust speed
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
socket not groundground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
socket with ground
16A/250V~
10pcs/box 100pcs/ctn



LY1-035
One waterproof German
French socket
16A/250V~
10pcs/box 100pcs/ctn



LY1-036
Double German socket
with groundground
16A/250V~
5pcs/box 50pcs/ctn



LY1-037
Double German socket
not groundground
16A/250V~
5pcs/box 50pcs/ctn



LY1-038
Double French socket
16A/250V~
5pcs/box 50pcs/ctn



LY1-039
3pin socket



LY1-040
4pin socket



LY1-001
Function key of
1 gang 1 way plate switch
LY1-002
Function key of
1 gang 2 way plate switch
LY1-003
Function key of
1 gang resetting plate switch



LY1-004
Function key of
2 gang 1 way plate switch
LY1-005
Function key of
2 gang 2 way plate switch
LY1-006
Function key of
2 gang resetting plate switch



LY1-007
Function key of
3 gang 1 way plate switch



LY1-008
Function key of 1 gang
1 way plate switch with LED light
LY1-009
Function key of 1 gang
2 way plate switch with LED light
LY1-010
Function key of
1 gang resetting plate switch



LY1-011
Function key of 2 gang
1 way plate switch with LED light
LY1-012
Function key of 2 gang
2 way plate switch with LED light
LY1-013
Function key of
2 gang resetting plate switch



LY1-014
Function key of
One German socket not
groundground



LY1-015
Function key of
One German socket with
groundground



LY1-016
Function key of
French socket



LY1-017
Function key of
One German socket with
groundground and Double USB



LY1-018
Function key of
One German socket with
groundground and A+TYPE C



LY1-019
Function key of
One German socket not
groundground with Double USB
(A+A,5V 2.1A)



LY1-020
Function key of
One German socket not
groundground with Double USB
(A+TYPE C,PD 20W)



LY1-021
Function key of
French socket with Double
USB(A+A,5V 2.1A)



LY1-022
Function key of
French socket with Double
USB(A+TYPE C,PD 20W)



LY1-023
Function key of
Double USB
(A+ TYPE C, PD 20W)



LY1-024
Function key of
TV socket



LY1-025
Function key of
Satellite socket



LY1-026
Function key of
TEL socket
LY1-027
Function key of
Computer(cat6A) socket



LY1-028
Function key of
Double TEL Socket
LY1-029
Function key of
TEL+Computer(cat6A) socket
LY1-030
Function key of
Double Computer(cat6A) socket



LY1-031
Function key of
TV+TEL Socket
LY1-032
Function key of
TV+Computer Socket



LY1-033
Function key of
Light dimmer switch(500W)
LY1-034
Function key of
Adjust speed



LY1-035
Function key of
One waterproof German
socket not groundground



LY1-035
Function key of
One waterproof German
socket with groundground



LY1-035
Function key of
One waterproof German
French socket



LY1-036
Function key of
A connected frame




LY1-037
Function key of
Two piece connected frame



LY1-038
Function key of
Three connected frames



LY1-039
Function key of
Four connected frames



LY1-040
Function key of
Five connected frames



LY1-001
Function key of
1 gang 1 way plate switch
LY1-002
Function key of
1 gang 2 way plate switch
LY1-003
Function key of
1 gang resetting plate switch



LY1-004
Function key of
2 gang 1 way plate switch
LY1-005
Function key of
2 gang 2 way plate switch
LY1-006
Function key of
2 gang resetting plate switch



LY1-007
Function key of
3 gang 1 way plate switch



LY1-008
Function key of 1 gang
1 way plate switch with LED light
LY1-009
Function key of 1 gang
2 way plate switch with LED light
LY1-010
Function key of
1 gang resetting plate switch



LY1-011
Function key of 2 gang
1 way plate switch with LED light
LY1-012
Function key of 2 gang
2 way plate switch with LED light
LY1-013
Function key of
2 gang resetting plate switch



LY1-014
Function key of
One German socket not
groundground



LY1-015
Function key of
One German socket with
groundground



LY1-016
Function key of
French socket



LY1-017
Function key of
One German socket with
groundground and Double USB



LY1-018
Function key of
One German socket with
groundground and A+TYPE C



LY1-019
Function key of
One German socket not
groundground with Double USB
(A+A,5V 2.1A)



LY1-020
Function key of
One German socket not
groundground with Double USB
(A+TYPE C,PD 20W)



LY1-021
Function key of
French socket with Double
USB(A+A,5V 2.1A)



LY1-022
Function key of
French socket with Double
USB(A+TYPE C,PD 20W)



LY1-023
Function key of
Double USB
(A+ TYPE C, PD 20W)



LY1-024
Function key of
TV socket



LY1-025
Function key of
Satellite socket




LY1-026
Function key of
TEL socket
LY1-027
Function key of
Computer(cat6A) socket



LY1-028
Function key of
Double TEL Socket
LY1-029
Function key of
TEL+Computer(cat6A) socket
LY1-030
Function key of
Double Computer(cat6A) socket




LY1-031
Function key of
TV+TEL Socket
LY1-032
Function key of
TV+Computer Socket



LY1-033
Function key of
Light dimmer switch(500W)
LY1-034
Function key of
Adjust speed




LY1-035
Function key of
One waterproof German
socket not groundground




LY1-035
Function key of
One waterproof German
socket with ground



LY1-035
Function key of
One waterproof German
French socket




LY1-036
Function key of
A connected frame




LY1-037
Function key of
Two piece connected frame



LY1-038
Function key of
Three connected frames



LY1-039
Function key of
Four connected frames



LY1-040
Function key of
Five connected frames



LY1-001
Function key of
1 gang 1 way plate switch
LY1-002
Function key of
1 gang 2 way plate switch
LY1-003
Function key of
1 gang resetting plate switch



LY1-004
Function key of
2 gang 1 way plate switch
LY1-005
Function key of
2 gang 2 way plate switch
LY1-006
Function key of
2 gang resetting plate switch



LY1-007
Function key of
3 gang 1 way plate switch



LY1-008
Function key of 1 gang
1 way plate switch with LED light
LY1-009
Function key of 1 gang
2 way plate switch with LED light
LY1-010
Function key of
1 gang resetting plate switch



LY1-011
Function key of 2 gang
1 way plate switch with LED light
LY1-012
Function key of 2 gang
2 way plate switch with LED light
LY1-013
Function key of
2 gang resetting plate switch



LY1-014
Function key of
One German socket not
groundground



LY1-015
Function key of
One German socket with
groundground



LY1-016
Function key of
French socket



LY1-017
Function key of
One German socket with
groundground and Double USB



LY1-018
Function key of
One German socket with
groundground and A+TYPE C



LY1-019
Function key of
One German socket not
groundground with Double USB
(A+A,5V 2.1A)



LY1-020
Function key of
One German socket not
groundground with Double USB
(A+TYPE C,PD 20W)



LY1-021
Function key of
French socket with Double
USB(A+A,5V 2.1A)




LY1-022
Function key of
French socket with Double
USB(A+TYPE C,PD 20W)



LY1-023
Function key of
Double USB
(A+ TYPE C, PD 20W)



LY1-024
Function key of
TV socket



LY1-025
Function key of
Satellite socket



LY1-026
Function key of
Double TEL socket
LY1-027
Function key of
Computer(cat6A) socket



LY1-028
Function key of
Double TEL Socket
LY1-029
Function key of
TEL+Computer(cat6A) socket
LY1-030
Function key of
Double Computer(cat6A) socket



LY1-031
Function key of
TV+TEL Socket
LY1-032
Function key of
TV+Computer Socket



LY1-033
Function key of
Light dimmer switch(500W)
LY1-034
Function key of
Adjust speed



LY1-035
Function key of
One waterproof German
socket not groundground



LY1-035
Function key of
One waterproof German
socket with ground




LY1-035
Function key of
One waterproof German
French socket




LY1-036
Function key of
A connected frame




LY1-037
Function key of
Two piece connected frame



LY1-038
Function key of
Three connected frames



LY1-039
Function key of
Four connected frames



LY1-040
Function key of
Five connected frames



LY1-001
Function key of
1 gang 1 way plate switch
LY1-002
Function key of
1 gang 2 way plate switch
LY1-003
Function key of
1 gang resetting plate switch



LY1-004
Function key of
2 gang 1 way plate switch
LY1-005
Function key of
2 gang 2 way plate switch
LY1-006
Function key of
2 gang resetting plate switch



LY1-007
Function key of
3 gang 1 way plate switch



LY1-008
Function key of 1 gang
1 way plate switch with LED light
LY1-009
Function key of 1 gang
2 way plate switch with LED light
LY1-010
Function key of
1 gang resetting plate switch



LY1-011
Function key of 2 gang
1 way plate switch with LED light
LY1-012
Function key of 2 gang
2 way plate switch with LED light
LY1-013
Function key of
2 gang resetting plate switch



LY1-014
Function key of
One German socket not
groundground



LY1-015
Function key of
One German socket with
groundground



LY1-016
Function key of
French socket



LY1-017
Function key of
One German socket with
groundground and Double USB



LY1-018
Function key of
One German socket with
groundground and A+TYPE C



LY1-019
Function key of
One German socket not
groundground with Double USB
(A+A,5V 2.1A)



LY1-020
Function key of
One German socket not
groundground with Double USB
(A+TYPE C,PD 20W)



LY1-021
Function key of
French socket with Double
USB(A+A,5V 2.1A)



LY1-022
Function key of
French socket with Double
USB(A+TYPE C,PD 20W)



LY1-023
Function key of
Double USB
(A+ TYPE C, PD 20W)



LY1-024
Function key of
TV socket



LY1-025
Function key of
Satellite socket



LY1-026
Function key of
TEL socket
LY1-027
Function key of
Computer(cat6A) socket



LY1-028
Function key of
Double TEL Socket
LY1-029
Function key of
TEL+Computer(cat6A) socket
LY1-030
Function key of
Double Computer(cat6A) socket




LY1-031
Function key of
TV+TEL Socket
LY1-032
Function key of
TV+Computer Socket



LY1-033
Function key of
Light dimmer switch(500W)
LY1-034
Function key of
Adjust speed



LY1-035
Function key of
One waterproof German
socket not groundground




LY1-035
Function key of
One waterproof German
socket with ground



LY1-035
Function key of
One waterproof German
French socket




LY1-036
Function key of
A connected frame



LY1-037
Function key of
Two piece connected frame



LY1-038
Function key of
Three connected frames



LY1-039
Function key of
Four connected frames



LY1-040
Function key of
Five connected frames